
Step 1

Select the proper RTSGO-01-Size marking gauge. Position the gauge on the end of the cut tube. Use a suitable marking pen to make the positioning marks. Remove the gauge.




Step 2

Install fitting on tube and use the positioning mark to position the edge of the unswaged fitting ring over the mark. The edge of the fitting ring may be anywhere along the length of the positioning mark.



Step 3

Select the correct size assembly tool. Attach the flexible hose with the mating quick disconnect coupling to the nipple at the bottom of the tool, and the nipple end of the hose to the mating quick disconnect coupling on the pump.



Step 4

Position the tool onto the fitting, with the ring nested into the movable jaw of the tool and the front opening of the tool bottomed into the fitting. Make sure that the fitting is bottomed into the tool.

Pressurize the tool to advance the fitting ring. Adequate pressure should be used to move the ring to its full forward position (approximately 8000-8500 psi). Release pressure. The movable jaw of the assembly tool will return to the original position.



Step 5


The fitting installation should be verified by visual inspection that the ring is fully advanced onto the fitting using the inspection gauge RTSGO-51-Size, which should fit over the ring after swaging. Also verify that the edge of the fitting is touching or over the inspection mark.

For detailed information on how to install Rynglok® fittings, please see the installation guide, Form No. TF100-67.






Rynglok tube fitting configuration



Rynglok fitting part number system and how to order


Basic part number designation



Example: R51003T10


Rynglok fitting, female ArcSeal (separable) to Rynglok fitting in the 90° elbow configuration.

How to Order




Example: RA0054D100608

Rynglok fitting, reducing tee, all legs permanent.



Example: L51054T080406

Lightweight Rynglok reducing tee, with female ArcSeal separable.



- ¹ Tube size is specified in 1/16" increments, (i.e., 08=8/16ths or 1/2")
- ² Port 2 and 3 only required for reducer fittings

NOTE: Port numbering system is in accordance with AIR 1590.

For additional information contact Eaton, Aerospace Group, Fluid & Electrical Distribution Division, 300 S. East Ave., Jackson, Michigan 49203 **Ph:** (517) 787-8121 **Fax:** (517) 789-2947.



Eaton
Aerospace Group
Conveyance Systems Division
300 South East Avenue
Jackson, Michigan 49203-1972
Phone: (517) 787 8121
Fax: (517) 789 2947
www.eaton.com/aerospace

© 2018 Eaton All Rights Reserved Printed in USA Form No. TF100-138 Supersedes: DS100-53 August 2018



All other trademarks are property of their respective owners.

