

FedEx Express Floor Lock Event

CMM 25-50-58

Disassembly of Cargo Lock (See Figure 14)

1. Ensure that pawls are folded down.
2. Beginning with the outer pawl, remove cotter pin and remove shaft.
3. Remove pawl and springs as applicable.
4. Observe locations of washers to assist in correct reassembly.
5. Repeat for the inner pawl.

Assembly of Cargo Lock (See Figure 14)

1. Install the pawls by placing two springs and the inner pawl into position on the base.
2. Engage the tangs of the springs in the holes of the pawls.
3. Insert one shaft through the base, the pawl, and the springs.
4. Install the washers as applicable.
5. Secure the shafts with two cotter pins. Repeat for the outer pawl.
6. Check the pawl operation.