


Third-Generation Tank Grade


ARM Fall Conference 2015, Denver CO


Henry Hay and Céline Bellehumeur, NOVA Chemicals November 2015


Contents

- Tank Resin History
- Tank Resin Requirements
- Resin Design and Characteristics
- Non-Tank Applications









What's New - SURPASS® RMs245-U/UG Gen 3 Resin Requirements

Ability to Mold Big Tanks

- Thermal Stability
- Consistent, Easy Mold Release
- Resistance to Warping
- Resistance to Sagging and Dripping

What's New - SURPASS® RMs245-U/UG Gen 3 Resin Requirements

Ability to Mold Big Tanks

- Thermal Stability
- Consistent, Easy Mold Release
- Resistance to Warping
- Resistance to Sagging and Dripping

High ESCR

1000+ hours (Bent Strip A100)

Very High Stiffness

1000+ MPa Flexural Modulus

High Toughness

What's New - SURPASS® RMs245-U/UG Gen 3 Resin Requirements

Ability to Mold Big Tanks

- Thermal Stability
- Consistent, Easy Mold Release
- Resistance to Warping
- Resistance to Sagging and Dripping

High ESCR

1000+ hours (Bent Strip A100)

Very High Stiffness

1000+ MPa Flexural Modulus

High Toughness

Hydrostatic Design Basis

1600 psi Cell Class

What's New - SURPASS® RMs245-U/UG **Gen 3 Resin Requirements**

Ability to Mold Big Tanks

- Thermal Stability
- Consistent, Easy Mold Release
- Resistance to Warping
- Resistance to Sagging and Dripping

High ESCR

1000+ hours (Bent Strip A100)

Very High Stiffness

1000+ MPa Flexural Modulus

High Toughness

Hydrostatic Design Basis

1600 psi Cell Class

UV Resistance

UV 15 +

What's New - SURPASS® RMs245-U/UG **Gen 3 Resin Requirements**

Ability to Mold Big Tanks

- Thermal Stability
- Consistent, Easy Mold Release
- Resistance to Warping
- Resistance to Sagging and Dripping

High ESCR

1000+ hours (Bent Strip A100)

Very High Stiffness

1000+ MPa Flexural Modulus

High Toughness

Hydrostatic Design Basis

1600 psi Cell Class


UV Resistance

UV 15 +


Process Flexibility

Ability to Mold Smaller Tanks → Resin Consolidation

The Challenge: Combining High Stiffness with ESCR, Toughness, and Processability



The Challenge: Combining High Stiffness with ESCR, Toughness, and Processability



FLEXURAL SECANT MODULUS 1% (MPa)

The Challenge: Combining High Stiffness with ESCR, Toughness, and Processability

- Target Values
 - → 1000+ h ESCR A100
 - → 1000+ MPa Flexural Modulus

The Challenge: Combining High Stiffness with ESCR, Toughness, and Processability

- Target Values
 - → 1000+ h ESCR A100
 - → 1000+ MPa Flexural Modulus

Strategy

Manipulate molecular weight & co-monomer distribution to achieve high stiffness combined with high ESCR

The Challenge: Combining High Stiffness with ESCR, Toughness, and Processability


- Target Values
 - → 1000+ h ESCR A100
 - → 1000+ MPa Flexural Modulus

Strategy


Manipulate molecular weight & co-monomer distribution to achieve high stiffness combined with high ESCR

THE FIX: SURPASS® RMs245-U/UG

- Specifications
 - 1.7 MI
 - 0.945 g/cm³




RMs245-U/UG Stiffness / ESCR Balance




FLEXURAL SECANT MODULUS 1% (MPa)

RMs245-U/UG Stiffness / ESCR Balance




FLEXURAL SECANT MODULUS 1% (MPa)

RMs245-U/UG Stiffness / ESCR Balance




FLEXURAL SECANT MODULUS 1% (MPa)


RMs245-U/UG Processing Window



RMs245-U/UG Processing Window



RMs245-U/UG Processing Window



Hydrostatic Design Basis




Executive Summary

The purpose of this project was to conduct hydre-HDPE Rotational Molding resin compound.

Based on the sample provided and the testing performed in this project, the following conclusion are made:

- Sample 14-393 meets as HDB of 1,600 psi at 73°F at the E-10 data distribution level.
- The sample validates an HDB of 1.600 psi at 73°F per Table 3 of ASTM D2837-13e1.





10,000 GALLON HD VERTICAL TANK

Image used with permission of Freeform Plastics



330 GALLON HORIZONTAL LEG TANK

Image used with permission of R.A.W. Tanks



330 GALLON TANK CONTAINMENT

Image used with permission of R.A.W. Tanks



IBC tank

Image by permission of Solar Plastics

300-GALLON TRASH CART -REPLACING XLPE

Image used with permission of Rotational Molding Inc.





LAUNDRY CART - Note straight walls


Used by permission of Rotational Molding Inc



2-lb PIPE RACK WITH KISSOFFS


Image by permission of Rotational Molding Inc.

RMs245-U/UG Other Properties




UP TO 10% FASTER PROCESSING

RMs245-U/UG Other Properties




10% HIGHER STIFFNESS

RMs245-U/UG Other Properties



20% HIGHER HDB RATING

RMs245-U/UG Other Properties



70% HIGHER ESCR

RMs245-U/UG Other Properties

- **Excellent Whiteness**
- Easy Mold Release
- **Excellent Interior Finish**
- Low Warping
- Good Flow in Smaller, More Complex Parts





PERFORMANCE DRIVEN, CUSTOMER INSPIRED.

novachemicals.com



© 2015 NOVA Chemicals - All rights reserved.

The information contained herein is provided for general reference purposes only. By providing the information contained herein, NOVA Chemicals makes no guaranty or warranty and does not assume any liability, with respect to the accuracy or completeness of such information, or product results in any specific instance, and hereby expressly disclaims any implied warranties of merchantability or fitness for a particular purpose or any other warranties or representations whatsoever, expressed or implied. Nothing contained herein shall be construed as a license to use the products of NOVA Chemicals in any manner that would infringe any patent. Nothing herein shall be copied, reproduced, distributed or otherwise used without the express written permission of NOVA Chemicals.

NOVA Chemicals' logo is a registered trademark of NOVA Brands Ltd.; authorized use/utilisation autorisée.

Responsible Care® is a registered trademark of the Chemistry Industry Association of Canada (CIAC).

Thanks to:

Freeform Plastics

R.A.W. Tanks

Rotational Molding Inc.

Solar Plastics

For generously allowing us to use the images shown in this presentation